

Technical Specification Rapid Firing System 10M

Length of Shock Tube	10 meters
Diameter of system	52 mm
Length of system	185 mm
Weight of system	210 g (appr.)
Strength of detonator	No.8
Transport class	1.4S



SHOCK TUBE SYSTEM™

RAPID FIRING SYSTEM 10M
The unique firing system from Norabel Ignition Systems



Norabel Ignition Systems AB
Box 154, SE-711 23 Lindesberg, Sweden
Phone: +46 581 872 25 Fax: +46 581 149 44
E-mail: info@norabel.com
www.norabel.com



Instruction to Rapid Firing System 10M


1. Remove the safety pin.




2. Unhook and remove the detonator holder, remove detonator.



3. Apply detonator to your object.




4. Uncoil the Shock Tube.




5. Remove the striker safety.



6. Trigger falls out.




7. Squeeze the trigger against outer casing and FIRE.



Extension of the firing distance

1. After uncoiling the Shock Tube, apply the second detonator into the detonator pocket in front of the uncoiled RFS 10M.



2. Proceed with the firing sequence as above, or make another extension of the firing distance as above.